


- Select MLM Net when hitting into a net indoors or outdoors.
- For optimal results, a well-lit environment and the use of white (not plastic or foam) golf balls is required.
- Accuracy is decreased in poorly lit environments. IMPORTANT: for optimal performance you must select the proper club before hitting; shot performance is affected by club selection.
- Proper alignment (MLM 6 feet behind the ball and aimed down your target line) and club selection (selecting your club in the MLM app before hitting the ball) are critical for

accurate metrics.





## MOBILE LAUNCH MONITOR

Have questions or need assistance? Email: support@rapsodo.com.

Rapsodo <sup>®</sup> MOBILE LAUNCH MONITOR		THE CINDOOR/OUTDOOR)	OUTDOOR
VIDEO	Video Play		
	Share Video		
	Shot Trace	×	
	Auto Club Recognition	×	
SESSIONS	Table View of Shots		
	Dispersion	$\checkmark$	
	Trajectories		
	Video Playback	$\checkmark$	
	GPS Shot Map	X	
METRICS	Distance	~	✓
	Ball Speed	$\checkmark$	$\checkmark$
	Club Speed	✓	~
	Smash Factor	$\checkmark$	
	Launch Angle	~	
	Launch Direction	$\checkmark$	
OTHER	Competitions	×	
	Games	×	
	Му Вад	$\checkmark$	~
	Airplay Compatible	$\checkmark$	$\checkmark$
	Setup	Requires 8 feet of ball flight	Requires 50 feet of ball flight
	Min. Requirements	iPhone XR and up, iPad Pro 2nd gen and newer (1080p @ 60FPS capable front camera)	iPhone 6s and up, iPad 2017 and up

MLM Outdoor: Recommended: iPhone 7 and up, iPad 2019 onward models (1080p capable front camera)

Rapsodo MLM app requires iOS 11 and above